



## Setting Time-Code on the Sony SRW-5500 HDCAM-SR

- **Press: Home** button
- **Press: TC** button
- **Set F1** to **TC**
- **Set F5** to **Ltc** or **Vitc**
- **Set F6** to **int (L or V)**  
\*Note: F7 needs to be on "Regen" to change F6
- **Set F7** to **preset**
- **Set F8** to **Rec Mode**
- **Enter Time-Code** using the number buttons
- **Press: Set** button (yellow)
- **Press: F3** (timer-set)
- **Press: Home** button

For more Tech-Tips like this one, visit <http://www.visionaryforces.com/>