



## Setting Time -Code on the Sony HDW-F500 HDCam

- Press: **Home** Button
- Press: **TC** Button. Using the **Number Buttons**, enter the Time-Code. Note that the TC Numbers appear on the top-right corner of the display.
- Press: **Set Button**
- Press: **F3** Button (Timer Set) . Make sure that **Timer Sel** and **TCR Source** are set to **INT** ( V/VITC or L/Longitude ).

For more Tech-Tips like this one, visit <http://www.visionaryforces.com/>